

RFA-4020 Unidapt™ Mega Kit

CONTENTS

- (2) **PT-4000-001**
Unidapt Female to UHF Male
- (2) **PT-4000-002**
Unidapt Female to Mini-UHF Male
- (2) **PT-4000-003**
Unidapt Female to N Male
- (2) **PT-4000-004**
Unidapt Female to BNC Male
- (2) **PT-4000-005**
Unidapt Female to TNC Male
- (2) **PT-4000-006**
Unidapt Female to SMA Male
- (2) **PT-4000-007**
Unidapt Female to UHF Female
- (2) **PT-4000-008**
Unidapt Female to Mini-UHF Female
- (2) **PT-4000-009**
Unidapt Female to N Female
- (2) **PT-4000-010**
Unidapt Female to BNC Female
- (2) **PT-4000-011**
Unidapt Female to TNC Female
- (2) **PT-4000-012**
Unidapt Female to SMA Female
- (9) **PT-4000-013**
Unidapt Male Universal Centers
- (2) **PT-4000-014**
Unidapt Females to RCA Males
- (2) **PT-4000-015**
Unidapt Females to RCA Female Phono Jacks
- (2) **PT-4000-016**
Unidapt Females to F Female
- (2) **PT-4000-017**
Unidapt Females to F Male
- (1) **PT-4000-026**
Unidapt Male Right-Angle
- (1) **PT-4000-027**
Unidapt Male T Adapter
- (2) **PT-4000-113**
Unidapt Female to SMB Male
- (2) **PT-4000-114**
Unidapt Female to SMB Female
- (2) **PT-4000-115**
Unidapt Female to MCX Male
- (2) **PT-4000-116**
Unidapt Female to MCX Female
- (2) **PT-4000-117**
Unidapt Female to MMCX Male
- (2) **PT-4000-118**
Unidapt Female to MMCX Female
- (2) **PT-4000-119**
Unidapt Female to 7-16 DIN Male
- (2) **PT-4000-120**
Unidapt Female to 7-16 DIN Female
- (2) **PT-4000-133**
Unidapt Female to RP SMA Male
- (2) **PT-4000-134**
Unidapt Female to RP SMA Female
- (2) **PT-4000-135**
Unidapt Female to RP TNC Male
- (2) **PT-4000-136**
Unidapt Female to RP TNC Female
- (1) **PT-4010-020**
Unidapt Male to Double Binding Post
- (1) **PT-4010-021**
Unidapt Male to Double Banana Plug
- (1) **RFA-4059-A1**
RF Sampler with Unidapt Male Terminations

Empty spaces are expansion slots for future additions.

